



## SPEEDLINE PUTTY PADS

The acoustic, intumescent putty pad is designed for lining electrical socket boxes in drywall constructions. The mouldable putty pads easily fit socket boxes to reduce sound travel through drywalls, whilst providing flexibility when fitting avoiding accidental tearing or puncturing.

Cutting an electrical socket opening in a drywall partition can reduce its acoustic performance and resistance to fire, which could therefore result in non-compliance with Part E and Part B Building Regulations.

**Speedline Putty Pads are the acoustically tested, intumescent solution, complying with Building Regulations Part E and Part B.**


### THE SPEEDLINE PUTTY PAD

**Strip size:** 3.6m per reel  
**Thickness:** 3.2mm  
**Width:** 178mm

Each reel is sufficient to cover at least **27 single boxes** or **20 double boxes**.

### SPEEDLINE PUTTY PAD FEATURES AND BENEFITS

- Maintains acoustic integrity of the wall, with a rating of up to 69dB Rw
- Provides 2 hour fire resistance
- Complies with Building regulations Part E and Part B
- Easy to use and install
- Minimal waste
- Flexible – one size fits all
- Cost effective – labour and time saving
- Reduced damage on site and in transit



## INSTALLATION GUIDE


The Putty Pads take only 2-3 minutes to fit:

### TO FIT A PAD INTERNALLY -


1. Use the printed grid to measure the length of pad required – approximately 6 grids for a single box and 8 for a double box.
2. Cut the pad and remove the protective paper from one side.
3. Make a slit for the cable and pass the cable through the pad.
4. Press the pad firmly into the socket box to ensure adhesion on all surfaces then mould into the corners.
5. Remove the second protective paper and trim any excess putty.  
The length can easily be varied to further reduce waste.

### TO FIT A PAD EXTERNALLY -

1. Use the printed grid to measure the length of pad required.
2. Cut with a sharp knife and remove the protective paper from one side.
3. Press the pad firmly over the back of the socket box to ensure adhesion on all sides.
4. Remove the second protective paper.



Quick & easy to fit



Protects in minutes



Speedline Putty Pads are available from the following stockists:



[www.sheffins.co.uk](http://www.sheffins.co.uk)



[www.kitsonsthermal.co.uk](http://www.kitsonsthermal.co.uk)



[www.warren.co.uk](http://www.warren.co.uk)



[www.sheffins.co.uk](http://www.sheffins.co.uk)



[www.woodsinsulation.co.uk](http://www.woodsinsulation.co.uk)



[www.solentinsulation.co.uk](http://www.solentinsulation.co.uk)

# CUT COSTS WITHOUT CUTTING QUALITY

This publication contains manufacturer's product information that is reproduced by SIG plc in good faith, based on the latest knowledge available. Whilst every effort has been made to ensure that the information is current and correct, as distributors SIG plc cannot accept responsibility for the application and performance levels of the products featured. Neither can we accept responsibility where the manufacturer's instructions have not been followed.